
PHONIC



WWW.PHONIC.COM

W User's Manual

MSK 8 MSK 10 MSK 12 MSK 15 MSK 18SB

Passive Speaker

ENGLISHI

V1 11/01/2021

USER'S MANUAL

CONTENTS

SAFETY INSTRUCTIONS	1
	1
SUGGESTED SETUP METHODS	1
FEATURES	1
SPECIFICATIONS	2
APPENDIX	
APPLICATIONS	1

Phonic preserves the right to improve or alter any information within this document without prior notice

IMPORTANT SAFETY INSTRUCTIONS

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus. The MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable.

Warning: the user shall not place this apparatus in the confined area during the operation so that the mains switch can be easily accessible.

- 1. Read these instructions before operating this apparatus.
- 2. Keep these instructions for future reference.
- 3. Heed all warnings to ensure safe operation.
- 4. Follow all instructions provided in this document.
- 5. Do not use this apparatus near water or in locations where condensation may occur.
- 6. Clean only with dry cloth. Do not use aerosol or liquid cleaners. Unplug this apparatus before cleaning.
- 7. Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.
- 8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plug, convenience receptacles, and the point where they exit from the apparatus.
- 11. Only use attachments/accessories specified by the manufacturer.
- 12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus

combination to avoid injury from tipover.



- Unplug this apparatus during lighting storms or when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK) NO USER SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED PERSONNEL



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient

magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

CAUTION: Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.

SAFETY INSTRUCTIONS

- 1. Read all instructions carefully before using your MSK Speakers.
- 2. Keep this safety and instruction flier for future reference.
- 3. Ensure you follow all instructions carefully.
- 4. When used in conjunction with Amplifiers or Powered Mixers ensure you follow the correct procedures in the set up and turning on and off of audio equipment. It is advisable, when an entire sound system is set up, that the power amplifier or powered mixer that you are using is turned on last (ie. That any source equipment, such as guitars, tape decks, etcetera, are turned on first). After all source equipment is turned on and have stabilized, ensure the power amp or powered mixer's level control is set to a minimal level and then activate, after which the level control can be set to a reasonable level. This should be done in reverse when shutting down: turn off the power amp or powered mixer first, then turn off all other devices. However many professional amplifiers feature delayed on/off circuits that can perform this automatically.
- <u>Warning</u> The MSK Speakers generate extremely high sound pressure levels. Ensure you take care in the placement and operation to avoid exposure to extremely high sound levels, to reduce to risk of causing permanent hearing damage.
- <u>Cables</u> Under no circumstances should you use shielded or microphone cables for connecting speakers to amplifiers. These cables are not heavy enough to be able to handle the amplifier load and could cause irreversible damage to your system.
- 7. Mounting The suspending, rigging and mounting of the MSK Speakers can cause members of the public to be exposed to serious health risk, as well as the possibility of death. If you are NOT fully qualified and certified to mount these speakers by relevant local, state, or national authorities, do not under any circumstances try to rig, suspend or mount this system. All relevant safety regulations must be followed. If you are not completely qualified or do not know of said regulations, ensure you consult qualified personnel for assistance.
- 8. Servicing Do not under any circumstances try to service this

product by yourself. If servicing is required, contact your local service center.

INTRODUCTION

The MSK represents the best of Phonic's speaker revolution. The MSK's visually stunning vertical curvature enhances audio dispersion and works with internal bracing to increase structural strength and to minimize diffraction. Phonic's proprietary designed horn, developed using computer-aided modeling, offers extremely balanced sound projection and low distortion even at high volumes. Our development team also crafted pure titanium compression tweeters and long-throw composite woofers to ensure the MSK's sound quality matches its stunning cosmetics. The durability of the MSK series is unmatched. The MSK is protected by multi-layer scratchproof paint. The MSK series is the most versatile in its class with heavey duty pole mounts, a 45° floor monitor position for two-way models, and ergonomic handles. With an unsurpassed audio response, sensational power handling, and fantastic flexibility, the MSK establishes a new benchmark.

FEATURES

- Internal bracing system increases structural strength
- New 1.74" pure titanium compression tweeter paired with Phonic's proprietary designed horn delivers smooth, transient highs beyond 20kHz
- Wide 90°x60° dispersion angle
- New long-throw composite woofers
- Professional Speakon In/Out Connections
- Serve as floor monitors when tilted on the side (Two-way models)
- Powder coated steel with acoustically transparent foam
- Multi-layer scratch-proof paint
- Integrated handles for easy carrying
- Full-band speakers with HF OCPP protection (Over Current Passive Protection)
- Subwoofer cabinet design with SWR (Stationary Wave Reduction) to reduce internal standing waves

Equalization

The MSK speakers are design to perfectly reproduce all audio signals as sent by your amplifier or powered mixer. As such, your equalization efforts do not need to take speaker response into account, rather your main concentration should be on the acoustics of the venue. If equalization is applied, it should be done so with the utmost of case. Applying overly harsh equalization can be detrimental to your overall sound.

Connection

The MSK speakers are equipped with professional Speakon speaker connectors on the rear of the speaker. The input connectors on each unit should be connected to an appropriate output device such as a power amplifier or powered mixer. The Speakon connectors do not need to be soldered into place; rather they are pushed into the socket and turned clockwise to lock. Once all equipment is turned off, twist the connector counter-clockwise to disconnect. The output connector can be used to run two (or more) speakers in parallel.

Speakon connector

Pin + = + on amplifier Pin - = - on amplifier

Impedances

The nominal impedance of the MSK speakers is 8 Ω . This means that a single MSK speaker can be used with an amplifier channel that can run down to 8 Ω . Similarly, two speakers can be used with an amplifier that can run at 4 Ω per channel and four speakers can be used with an amplifier that can run at impedances of 2 Ω (check the amplifier's recommended operation before doing so).

Operation

When making a connection, be sure to turn off the amplifier that you are connecting to. Use professional Speakon connectors and cables only. Once connections are made, turn the amplifier on with all channels set to the zero position. Be sure not to drive the amplifier to the point of overload or clipping for any length of time as to ensure the integrity of the speaker's voice coil.

SPECIFICATIONS

Model Name	MSK 8	MSK 10	MSK 12	MSK 15	MSK 18SB
System Type	8" 2-Way Stage	10" 2-Way Stage	12" 2-Way Stage	15" 2-Way Stage	
	Speaker and Floor	Speaker and Floor	Speaker and Floor	Speaker and Floor	18" Subwoofer
	Monitor	Monitor	Monitor	Monitor	
Frequency Response (- 10dB)	78Hz-18kHz	62Hz-18kHz	60Hz-18kHz	51Hz-18kHz	40Hz-250Hz
Power Handling (RMS)	150W	250W	300W	400W	700W
Power Handling					
(Music)	300W	500W	600W	800W	1400W
Power Handling (Peak)	600W	1000W	1200W	1600W	2800W
Sensitivity 1W@1M	98/dB	99dB	98dB	99dB	100dB
System Impedance	8ohm	8ohm	8ohm	8ohm	4ohm
Woofer	8"	10"	12"	15"	18"
Woofer Voice Coil	50mm / 2in	63.5mm / 2.5in	63.5mm/2.5in	75mm/3in	100mm/4.0in
Tweeter	1.34" Titanium	1.34" Titanium	1.74" Titanium	1.74" Titanium	-
Horn and					
System Dispersion	90°Hx60°V	90°Hx60°V	90°Hx60°V	90°Hx60°V	-
SPL	121dB	123dB	128dB	130dB	131dB
Exterior	Textured black paint				
Grille	Powder coated steel with acoustically transparent foam				
Wood type	18mm MDF				
Pole Mount	Heavy Plastic				
Handles	Wood handle (Integrated)	Wood handle (Integrated)	Wood handles (Integrated)	Wood handles (Integrated)	Wood handles (Integrated)
Net Weight	8kg/17.6lbs	13.5kg/29.7lbs	19kg/41.8lbs	20kg/44.1lbs	40kg/88.1lbs
Unit Dimension (HxWxD)	376x234x234mm (17.7x11.2x10.8in)	504xx324x311mm (19.9x13.0x12.8in)	612x378x304mm (24.7x15.5x14.6in)	684x432x354mm (28.2x18.1x17.1in)	684x504x595mm (21.1x24.4x24.4in)
Connectors	Speakon x 2				

SERVICE AND REPAIR

For replacement parts, service and repairs please contact the Phonic distributor in your country. Phonic does not release service manuals to consumers, and advice users to not attempt any self repairs, as doing so voids all warranties. You can locate a dealer near you at http://www.phonic.com/where/.

WARRANTY INFORMATION

Phonic stands behind every product we make with a no-hassles warranty. Warranty coverage may be extended, depending on your region. Phonic Corporation warrants this product for a minimum of one year from the original date of purchase against defects in material and workmanship under use as instructed by the user's manual. Phonic, at its option, shall repair or replace the defective unit covered by this warranty. Please retain the dated sales receipt as evidence of the date of purchase. You will need it for any warranty service. No returns or repairs will be accepted without a proper RMA number (return merchandise authorization). In order to keep this warranty in effect, the product must have been handled and used as prescribed in the instructions accompanying this warranty. Any tampering of the product or attempts of self repair voids all warranty. This warranty does not cover any damage due to accident, misuse, abuse, or negligence. This warranty is valid only if the product was purchased new from an authorized Phonic dealer/distributor. For complete warranty policy information, please visit http://www.phonic.com/warranty/.

CUSTOMER SERVICE AND TECHNICAL SUPPORT

We encourage you to visit our online help at http://www.phonic.com/support/. There you can find answers to frequently asked questions, tech tips, driver downloads, returns instruction and other helpful information. We make every effort to answer your questions within one business day.

support@phonic.com http://www.phonic.com

PHONIC

