

MX306 3-Channel DJ Mixer with BPM

- ▶ Three phono, three Line and three Mic inputs
- ▶ BPM display & beat offset indicators
- ▶ Push button cueing with cue/program pan control
- ▶ 3-band EQ (-30dB to +15dB) with gain control on each program channel
- ▶ 12V BNC gooseneck lamp jack
- ▶ Talkover switch



FEATURES

- ▶ Three phono, three Line and three Mic inputs
- ▶ BPM display
- ▶ Beat offset indicators
- ▶ Talkover switch
- ▶ Push button cueing with cue/program pan control
- ▶ 3-band equalizer (-30 dB to +15 dB) and gain control on each program channel
- ▶ Master and DJ booth output level control
- ▶ Master output with balance control
- ▶ LED output display for master and cue level
- ▶ 12V BNC gooseneck lamp jack
- ▶ Built-in power supply - no wall wart!
- ▶ Ultra durable crossfader (replaceable)

The MX306 is a 3-channel Mixer with a total of 9 inputs (3 phono, 3 Line and 3 Mic) and gain controls, complete with 3-band system EQ. The master level LED display and beat indicators (for easy synchronization) really put you in control of your music. Also featured are talkover switch, cue button, headphone jacks for monitoring and a 12V light jack. The MX306 is ideal for small-to-medium size clubs.

SPECIFICATIONS

	MX 306
Input	3 phono, 3 line, 3 mic
Output	1 master, 1 rec 1 booth via RCA
Minimum Input Voltage	
Phono	3.2mV RMS, 47kOhms
Line	150mV RMS, 47kOhms
Microphoe	3mV RMS, 2.2kOhms
Output Voltage	
Line	7V RMS max.
Headphones	0.4V
Frequency Range	+/-3 dB
Phono	20Hz ~ 2KHz
Line	10Hz ~ 50KHz
Microphone	20Hz ~ 20KHz
Distortion	<0.05%
S/N Ratio	
Phono	-50dB
Line	-64dB
Microphone	-60dB
Talkover Attenuation	-14dB
Headphones Impedance	8 Ohms
Tone Control	
Treble	40KHz,-30dB ~ 15dB
Middle	1KHz,-30dB ~ 15dB
Bass	40Hz,-30dB ~ 15dB
Dimension(W x D x H)	254x 320 x99 (mm)
Weight	3.5 (kg)
Power Supply	115/230V, 50/60Hz
Power Consumption	30 W

